


Pos.	Qty	Denomination	1"	1½"	2"
Actuator					
		Actuator, complete (NO).....	9613-1447-10	9613-1447-10	9613-1447-11
		Actuator, complete (NC).....	9613-1447-13	9613-1447-13	9613-1447-14
		Actuator, complete (A/A).....	9613-1447-16	9613-1447-16	9613-1447-17
	1	Cylinder	9613-1425-04	9613-1425-04	9613-1425-05
	2	Piston	9613-1322-01	9613-1322-01	9613-1323-01
▲*	3	O-ring			
	5	Adapter.....	9613-1274-01	9613-1274-01	9613-1274-01
▲*	6	Bushing			
▲*	7	O-ring			
▲*	8	O-ring			
	9	Plug.....	9613-4141-01	9613-4141-01	9613-4141-01
	10	Lock wire	9613-1432-01	9613-1432-01	9613-1432-02
▲*	11	O-ring			
	12	1 (2) (only 2 for A/A) Air fitting.....	9611-99-4682	9611-99-4682	9611-99-4682
	14	Spring assembly	9613-1325-01	9613-1325-01	9613-1325-02
	15	Bottom	9613-1327-01	9613-1327-01	9613-1327-02
*	16	Support disc (only A/A)			
Bonnet					
	13	Yoke	9613-1330-01	9613-1330-01	9613-1331-01
	17	Washer	9611-99-1888	9611-99-1888	9611-99-1888
	18	Nut	9611-99-0360	9611-99-0360	9611-99-0360
Service kits					
▲		Service kit, Actuator, NO , NC.....	9611-92-6497	9611-92-6497	9611-92-6498
*		Service kit, Actuator, A/A	9611-92-6519	9611-92-6519	9611-92-6520

Parts marked with ▲/* are included in the service kits (actuator)

Recommended spare parts: Service kits



Pos.	Qty	Denomination	2½"	3"	4"
Actuator					
		Actuator, complete (NO)	9613-1447-11	9613-1447-12	9613-1447-12
		Actuator, complete (NC)	9613-1447-14	9613-1447-15	9613-1447-15
		Actuator, complete (A/A).....	9613-1447-17	9613-1447-18	9613-1447-18
	1	Cylinder	9613-1425-05	9613-1425-06	9613-1425-06
	2	Piston.....	9613-1323-01	9613-1324-01	9613-1324-01
▲*	3	O-ring.....			
	5	Adapter	9613-1274-01	9613-1274-01	9613-1274-01
▲*	6	Bushing.....			
▲*	7	O-ring.....			
▲*	8	O-ring.....			
	9	Plug	9613-4141-01	9613-4141-01	9613-4141-01
	10	Lock wire	9613-1432-02	9613-1432-03	9613-1432-03
▲*	11	O-ring.....			
	12	1 (2) (only 2 for A/A) Air fitting.....	9611-99-4482	9611-99-4682	9611-99-4682
	14	Spring assembly.....	9613-1325-02	9613-1325-03	9613-1325-03
	15	Bottom.....	9613-1327-02	9613-1327-03	9613-1327-03
*	16	Support disc (only A/A).....			
Bonnet					
	13	Yoke.....	9613-1332-01	9613-1333-01	9613-1334-01
	17	Washer.....	9611-99-1888	9611-99-1888	9611-99-1888
	18	Nut.....	9611-99-0360	9611-99-0360	9611-99-0360
Service Kits					
▲		Service kit, Actuator, NO , NC	9611-92-6498	9611-92-6499	9611-92-6499
*		Service kit, Actuator, A/A.....	9611-92-6520	9611-92-6521	9611-92-6521

Parts marked with ▲/* are included in the service kits (actuator)

Recommended spare parts: Service kits