



Anderson Instrument Co., Inc.
156 Auriesville Rd.
Fultonville N.Y. 12072

Phone: 518-922-5315 or 800-833-0081
Fax: 518-922-8997 or 800-726-6733

Technical Bulletin

AV-9000 / AV-9900 Chart Recorder
Time Change



NOTE: Model AV-9900 ONLY

The chart rotation MUST be stopped. Time change not allowed while processing.

1. to **SELECT** **CONFIGURATION**
- 2.
3. to **CONFIGURE** **INSTRUMENT SETTINGS**
- 4.
5. to **CURRENT TIME**
AM/PM **XX:XX** **XX**
6. **Cursor appears under hours**
7. or to change hours
8. to program new hours
9. or to change minutes
10. to program new minutes
11. or to change AM/PM
12. to program AM/PM
13. to return to main display